For more information, view our Web site at www.postcaps.com





## To activate your new solar post cap:

- Remove top by pressing inward on the side of the clear lens, grasping the edge of the top and lifting it off.
- Install the batteries.
- Replace top by snapping onto side panels. (Ensure the holes in the sides are matched up with the stubs on the top.)
- Place your solar post cap in direct sunlight for 24-48 hours to fully charge.

Your solar post cap light is now ready to be installed onto your post.



To attach your post cap to the post, apply exterior-grade construction adhesive to the underside of the post cap before placing the cap firmly on the post.

## www.postcaps.com

©2010 Universal Forest Products, Inc. All rights reserved. Maine Ornamental is a registered trademark of Universal Consumer Products, Inc., in the U.S.