
For more information, visit our Web site at Raftertails.com



A superior, slide-on alternative to conventional rafter tails



- Lowest installed cost better than solid sawn or foam
- Perfect for remodel or new home construction
- Environmentally friendly 70% less wood than solid sawn and 100% lower carbon footprint than foam

RafterDe Tails
Slide-on Wood Rafter Tails



RafterDeTTails are environmentally friendly and durable in all climates.

RafterDeTTails are all-wood, kiln-dried, laminated, non-structural, decorative rafter tails that are designed to slide onto the cantilevered end of a roof truss. This eliminates the need for running the corbelled member back past the wall into the roof/truss space, as is commonly done with conventional solid-sawn rafter tails. The RafterDeTTail is then fastened to the truss chord using nails or wood screws. Starter boards and roof sheathing can be installed in the conventional manner.




RafterDeTTails are manufactured using custom-laminated wood and are guaranteed not to delaminate. The wood is carefully kiln dried, and all RafterDeTTails are double primed. This virtually eliminates most cracks and splits that are prevalent in solid-sawn timbers.


As shown on the right, RafterDeTTails are available in two styles: profile #3 and profile #18. Styles measure 4×6 ($3\frac{1}{2}$ " \times $5\frac{1}{2}$ "), both in 26" long lengths.

RafterDe Tails

Slide-on Wood Rafter Tails

profiles available:





Order Form


Profile #	Designation	Quantity
	Total	

Both profiles are 4 x 6 (3½" x 5½") resawn, double primed Note: customer to prime any cut surfaces prior to installation.

Completing the Order Form:

- 1. If more than one profile is being ordered, give each profile a designation (i.e., Type 1, Type 2).
- 2. Fill in the quantity of each type/designation.

Note: Depending on the length of the actual roof overhang, the length of the RafterDeTTail may have to be field trimmed to suit. A field trim – slope/pitch cut to the back side of the RafterDeTTail may also be required.



Recommended nailing schedule

Conventional nailing and framing practices should be used when attaching RafterDeTTails.

- 1. First row of nails to be a minimum of 1" below top of truss tail.
- 2. First nail at the front of the RafterDeTTail to be no closer than 1" from the end of the truss tail.
- 3. Nails to be spaced no closer than 3" oncenter on alternate sides of the RafterDeTTail. Rows to be staggered 1.5" minimum.
- 4. First nail at the back of the RafterDeTTail to be no closer than 4" from the back of the RafterDeTTail. Galvanized nails are highly recommended. For 4x RafterDeTTails, use 8d(0.113) x 2.5" or 2.75". A 16-gauge 2.5" brad nail is also suitable. For 6x RafterTTails, use 10d(0.131) x 3".

Visit www.raftertails.com for complete installation details.

Note: Improper or over-nailing will void the RafterDeTTail warranty and may cause splitting. Appropriate spacing should also be considered if brad nails or screws are used. Any exposed woodgrain from cutting or trimming must be pre-primed to avoid voiding the warranty.



Distributed by:



The tree logo is a registered trademark of Universal Forest Products, Inc., in the United States. © 2007 Universal Forest Products.

All rights reserved. 4587-233/382